

**Please observe the following instructions for wall mounting or operation of ILUMAG top, ILUMAG flex, ILUMAG perm and ILUTEX frame**

- The systems usually have 10 mm flat aluminum profile rails on the back for hanging.
- To fix the wall brackets (hooks, eccentrics or holding rails), please use a screw and dowel system suitable for the wall material (e.g. brick, drywall or concrete).
- For the electrical connection, connect one end of the supplied connection cable in the correct polarity (+/-) to the WAGO terminal on the rear of the system and the other end to the 12/24 V socket of the power supply unit.
- The power pack must be connected to a 230 V socket with its 230 V plug.
- If the power supply unit does not have a plug, but has connecting wires if desired, these must be connected to the appropriate terminals by a specialist. Work on the 230 V mains, e.g. to connect a transformer with terminals to the 230 V mains, may only be carried out by an electrician (specialist).
- If a dimmer is available, you can adjust (dim) the brightness of the system using the supplied remote control.
- During commissioning, the supplied instructions for the components must be observed.
- If the system does not light up as desired after connection, please change the polarity of the connection wires at the WAGO terminal on the rear. If this is not successful, please contact us.

**Please do not hesitate to contact us if you have any questions.**

**Good luck with the image change!**